



20-




VALVE













•







.










.



	Help			Mater	ial Pun	Material Pump Setup	<u>a</u>				
			ਠੋ	rently Sek	Currently Selected Spacer Size:	cer Size:	25/	/32			
	S	Sealant Sic	Side + Bottom Pump	ttom Pur	d d						
	Spacer Size	Pump On P Dly Start (Sec)	On Pump Off Pump On Pump Off art Dly Stop Dly Skip (Sec) (Sec)	Pump On Dly Skip (Sec)	Pump Off Dly Skip (Sec)	Pressure Setpoint (psi)	Pump Accel (Sec)	Pump Decel (Sec)	Side Thick (Sec)	Bottom Thick (Sec)	
	26/32	-0.08	0.00	0.00	0.02	1000.00	0.05	0.05	0.030	0.030	
	Purge Pressure		1500.00	psi Make	e All Sealant	Sizes	Equal	Sealant	ant Pump	DISABLED	
	-Matrix Pump	Pump									
		Spacer Size		Pump On Pump Off Delay Delay (Sec) (Sec)	f Pressure Setpoint (psi)	Accel (Sec)	Pump Decel (Sec)		Matrix Weight (g/ft)		
		26/32	-0.03	0.00	00.009	0.05		0.05	10.00		
	Purge Pressure		Matrix Thickness/Weight Calculator Spacer Size (in.) Weight (g/ft) ⊓hic psi 26/32 □ □	kness/We	/eight Cak weight (g/ft)	culator Thickness (in.)	s (in.)	Make A Matrix	All Matrix rix Pump	Sizes - DISA	Equal
<u> </u>	Maintenance Menu		Save Pump Settings		Load GED Defaults	Load User Settings	User	Sav	Save User Settings		

<u>|</u>

312